

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 1

Excavation of a Pond or Containment Structure



Step 1- Remove all vegetation, rock or debris that is 0.5" (12.7 mm) or larger.



Step 2- Compact the soil to 85 to 95% of Standard Proctor density.



Step 3- Compact any soil around penetrations or masonry structures to 95% of Standard Proctor density.



Step 4- Drain any water prior to laying the Firestone EPDM Geomembrane.