

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 3

Deploying a Geotextile Downslope



Step 1- Starting at the apex of the slope, deploy the geotextile downhill.



Step 2- If necessary; apply a temporary ballast or mechanical attachment to the soil.



Step 3- Trim the geotextile to fit.

This Detail featured these Firestone Products:

Product

- Firestone Geotextile

Item #

Varies by Size