

### PondGard™ Rubber Liner Installation Detail 3

#### **Deploying a Geotextile Downslope**



**Step 1**- Starting at the apex of the slope, deploy the geotextile downhill.



**Step 2**- If necessary; apply a temporary ballast or mechanical attachment to the soil.



**Step 3**- Trim the geotextile to fit.

#### **This detail featured these Firestone Products:**

##### **Product**

- Firestone Geotextile

##### **Item #**

Varies by Size