

## Firestone EPDM Geomembrane Installation Detail 4

### **Deploying a Geotextile Up a Slope**



**Step 1**- Unroll the geotextile.



**Step 2**- If necessary; apply a temporary ballast or mechanical attachment to the soil.



**Step 3**- Trim the geotextile to fit.

### **This Detail featured these Firestone Products:**

**Product**

- Firestone Geotextile

**Item #**

Varies by Size