

PondGard™ Rubber Liner Installation Detail 4

Deploying a Geotextile Up a Slope



Step 1- Unroll the geotextile.



Step 2- If necessary; apply a temporary ballast or mechanical attachment to the soil.



Step 3- Trim the geotextile to fit.

This detail featured these Firestone Products:

Product

- Firestone Geotextile

Item #

Varies by Size