

# Firestone

## SPECIALTY PRODUCTS

---

### Firestone EPDM Geomembrane Installation Detail 5 **Using Sod Staples to Hold Geotextile Against Wind Uplift**



**Step 1-** Use sod staples to hold the geotextile in place.



**Step 2-** Remove all bent or excess staples that pose a hazard of puncturing the Firestone EPDM Geomembrane.

#### **This Detail featured these Firestone Products:**

##### **Product**

- Firestone Geotextile

##### **Item #**

Varies by Size