

Firestone EPDM Geomembrane Installation Detail 7 **Unfolding a Roll of Firestone EPDM Geomembrane**



Step 1- Unfold the Firestone EPDM Geomembrane, keeping the leading edge down so that it is not blown by the wind.



Step 2- Once completely unfolded, the panel can be moved by flapping it, to introduce air under the membrane.



Step 3- Use scissors to trim the membrane to fit.

Note: Do not use a knife.

Notes:

1. Wrinkles do not typically affect the service life of the Firestone EPDM Geomembrane but may affect the appearance of the membrane.
2. Wrinkles must be avoided in and around seams.

This Detail featured these Firestone Products:

Product

- Firestone EPDM Geomembrane

Item #

Varies By Size