

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 8 **Install a Repair Patch Using a QuickSeam™ Repair Kit**



Step 1- Ensure the liner is dry and free of mud or other contaminants.



Step 2- Apply the QuickPrime™ Plus Primer by pouring a small amount onto the scrubber pad and applying it to the surface of the Firestone EPDM Geomembrane beyond the perimeter of the area to be repaired with a patch.



Step 3- Test the primer flash-off by touching the primed area with your finger and pushing forward at an angle. The primer should not string as your finger is moved up and away.



Step 4- Install the QuickSeam patch by peeling away the release paper and placing the patch over the damaged area of the liner.

Note: Edges of the QuickSeam patches may be rounded or cut diagonally to prevent peeling.

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 8 (Con't)

Install a Repair Patch Using a QuickSeam Repair Kit



Step 5- Roll the patch evenly over the area to be repaired in order to properly mate the patch and liner together.

Note: If the area cannot be adequately repaired using the two 6.00" by 6.00" (15.24 cm x 15.24 cm) QuickSeam patches, call Firestone Specialty Products at 800-428-4442 for additional assistance.

This Detail featured these Firestone Products:

Product

- Firestone EPDM Geomembrane
- QuickSeam Repair Kit

Item #

Varies By Size
W56RAC0030