

PondGard™ Rubber Liner Installation Detail 9

Removing an Air Bubble from a Taped Seam



Step 1- Attempt to hand roll the bubble to the edge of the 6.00" (15.24 cm) QuickSeam™f Cover Strip.



Step 2- If unable to roll the bubble out, lance it.



Step 3- Using standard seaming procedures; cover the lanced hole with a patch of QuickSeam Cover Strip.

Notes:

1. You must extend patch a minimum of 3.00" (7.62 cm) beyond any cuts.
2. Caulk if necessary.
3. Similar procedures can be used on 3.00" (7.62 cm) Splice Tape

Firestone

SPECIALTY PRODUCTS

PondGard Rubber Liner Installation Detail 9 (Con't)

Removing an Air Bubble from a Taped Seam

This Detail featured these Firestone Products:

Product

- PondGard Rubber Liner
- 6.00" (15.24 cm) QuickSeam Cover Strip
- QuickPrime™ Plus Primer
- QuickScrubber™
- Hand Roller

Item #

Varies By Size
W56RAC1616
or
W56RAC1693
or
W563587041
or
W563587044
W563582045
W563582023