

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 13

Removing an Air Bubble from a Taped Seam



Step 1- Attempt to hand roll the bubble to the edge of the 6.00" (15.24 cm) QuickSeam™ Cover Strip.



Step 2- If unable to roll the bubble out, lance it.



Step 3- Using standard seaming procedures; cover the lanced hole with a patch of QuickSeam Cover Strip.

Notes:

1. You must extend patch a minimum of 3.00" (7.62 cm) beyond any cuts.
2. Caulk if necessary.

Note: Similar procedures can be used on 3.00" (7.62 cm) Splice Tape

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 13 (Con't)

Removing an Air Bubble from a Taped Seam

This Detail featured these Firestone Products:

Product

- Firestone EPDM Geomembrane
- 6" (15.24 cm) QuickSeam Cover Strip
- QuickPrime™ Plus Primer
- QuickScrubber™
- Hand Roller

Item #

Varies By Size
W56RAC1616
or
W56RAC1693
or
W563587041
or
W563587044
W563582045
W563582023