

Firestone

SPECIALTY PRODUCTS

Firestone EPDM Geomembrane Installation Detail 14 **Extend Seaming Technique into the Anchor Trench**



Step 1- Ensure the liner is dry and free of mud or other contaminants.



Step 2- Apply the QuickPrime™ Plus Primer several inches (approximately 7.62 cm) down into the anchor trench.



Step 3- Make sure to apply below any point at which the Firestone EPDM Geomembrane could be exposed.

This Detail featured these Firestone Products:

Product

- Firestone EPDM Geomembrane
- QuickPrime Plus Primer
- QuickScrubber™

Item #

Varies By Size
W563587041
or
W563587044
W563582045