

## PondGard™ Rubber Liner Installation Detail 14

### **Installing an Inside QuickSeam™ Corner Flashing**



**Step 1**- Ensure the liner is dry and free of mud and other contaminants.



**Step 2**- Trim the PondGard panel so 4.0" (10.16 cm) will overlap the other wall to prevent leakage above the inside QuickSeam corner flashing.



**Step 3**- Cut the bottom of the PondGard panel at an angle into the corner to facilitate the inside corner flashing.



**Step 4**- Upon completion, the corner should look like this, with the PondGard panel slightly wrapped around the next wall.

# Firestone

## SPECIALTY PRODUCTS

---

### PondGard Rubber Liner Installation Detail 14 (Con't)

#### **Installing an Inside QuickSeam Corner Flashing**



**Step 5-** Using a scrubber pad and holder; apply QuickPrime™ Plus Primer to a 14.0" by 14.0" (35.56 cm x 35.56 cm) area of the corner. Make sure to extend the primer past the adhered corner flashing.



**Step 6-** Test the primer flash-off by touching the primed area with your finger and pushing forward at an angle. The primer should not string as your finger is moved up and away.



**Step 7-** Fold the corner flashing in half with the perforated edge on the bottom.



**Step 8-** Remove the smaller portion of the release paper.

### PondGard Rubber Liner Installation Detail 14 (Con't)

#### **Installing an Inside QuickSeam Corner Flashing**



**Step 9-** Place the removed portion of the release paper in the folded flashing to facilitate installation.



**Step 10-** Fold the corner flashing in half again to form a one quarter (1/4) circle.



**Step 11-** Place the corner flashing 0.25" (0.64 cm) from the corner with the short side folded down.



**Step 12-** Press the QuickSeam Corner Flashing tightly into the 90° angle and unfold into the corner.

# Firestone

## SPECIALTY PRODUCTS

---

### PondGard Rubber Liner Installation Detail 14 (Con't)

#### **Installing an Inside QuickSeam Corner Flashing**



**Step 13-** Remove the larger portion of the release paper and mold the flashing into the remaining 90° angle, forming a pig-ear shaped fold just above the corner convergence.



**Step 14-** Using a scrubber pad and holder; apply QuickPrime Plus Primer to both sides of the pig-ear shaped fold and beyond.



**Step 15-** Before proceeding further; test the primer's flash-off in the same manner as before.



**Step 16-** Fold the pig-ear over using the primer as an adhesive to hold the fold of the flashing in place.

# Firestone

## SPECIALTY PRODUCTS

---

### PondGard Rubber Liner Installation Detail 14 (Con't)

#### **Installing an Inside QuickSeam Corner Flashing**



**Step 17-** Cover the pig-ear fold with a second QuickSeam Corner Flashing.

**Note:** It is important not to over-stretch the QuickSeam Corner Flashing while adhering it. A loss of the embossed pattern indicates over-stretching.



**Step 18-** Using QuickPrime Plus, make sure to prime all surface areas that the QuickSeam Flashing will contact.



**Step 19-** Remove the release paper and center the tape or flashing in the corner and over the pig-ear fold.



**Step 20-** Using a hand roller; roll the flashing to insure adhesion.

# Firestone

## SPECIALTY PRODUCTS

---

### PondGard Rubber Liner Installation Detail 14 (Con't)

#### **Installing an Inside QuickSeam Corner Flashing**



**Step 21-** Apply a continuous bead of Lap Sealant HS or All Purpose Sealant over the edges of all tape or flashing.

**Note:** A heat gun may be necessary to form the flashing during weather less than 45°F (7.22 °C).

#### **This Detail featured these Firestone Products:**

##### **Product**

- PondGard Rubber Liner
- QuickPrime Plus Primer
  
- QuickSeam Corner Flashing
- Water Block Seal
- Lap Sealant HS
- All Purpose Sealant
- QuickScrubber™
- Hand Roller

##### **Item #**

Varies By Size  
W563587041  
or  
W563587044  
W56RAC1647  
W563587071  
W563587031  
W563587078  
W563582045  
W563582023